

# STEP 1


Insert Long Retention Bolts into Holes 1 and 3 of Bracket.





## STEP 2

Place Bracket on Hard, Stable Surface with Edge on Hole 2.



## STEP 3

Pry Long Retention Bolts apart to start bending Bracket.



Pry until you achieve a 90 Degree Bend in the Bracket.



**DONE!** Modified Bracket is roughly 1.5 to 2 inches shorter than standard.

